

WARNING!

**FAILURE TO PROPERLY PRIME OIL SYSTEM WILL
DAMAGE ENGINE AND VOID WARRANTY!!!!**

DO NOT USE STARTER TO PRIME OIL SYSTEM!!!!!!!!!!!!!!!!!!!!!!

YOU MUST PRIME THE OIL SYSTEM!

USE AN AIR OVER HYDRAULIC SYSTEM SUCH AS:

MELLING MPL-101



www.melling.com/Aftermarket/Stock-Products/Engine-PreLube

DO NOT USE STARTER TO PRIME OIL SYSTEM!!!!!!!!!!!!!!!!!!!!!!

**FAILURE TO PROPERLY PRIME OIL SYSTEM COULD
DAMAGE ENGINE AND VOID WARRANTY!!!!**